



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
4. MOUNTING HOLES FROM CUSTOMER SUPPLIED TRIM TO BE DRILLED ON SITE
5. FOR MORTISE - SEE T1160

| | | | | | |
|---|--|---|--|---|--------------------------|
| RESPONSIBILITY Door and Frame Manufacturers are responsible for providing adequate construction or reinforcement for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced door and frames regardless of the type, material or method of construction. | | TEMPLATE FOR METAL / ALUMINUM DOOR 03 CBK | | HDG. _____ DR. _____  DO NOT SCALE DRAWING | |
| | | | | DATE 8/29/06 | TEMPLATE NUMBER T1157 |