



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
4. MOUNTING HOLES FROM CUSTOMER SUPPLIED TRIM TO BE DRILLED ON SITE
5. FOR MORTISE - SEE T1162

HDG. _____ DR. _____

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 03 CBK

DETEX[®]

DO NOT SCALE DRAWING

DATE 6-16-11	TEMPLATE NUMBER T1158
-----------------	--------------------------