



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
  2. DIMENSIONS SHOWN IN INCHES AND (mm).
  3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**RESPONSIBILITY**  
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

**TEMPLATE**  
 METAL/ALUMINUM DOOR  
 02D/02DT/02DU  
 WIDE LEVER TRIM  
 BP-5 MOUNTING PLATE

**DETEX**  
CORPORATION

DO NOT SCALE DRAWING

DATE 11/16/07	TEMPLATE NUMBER T1150
------------------	--------------------------