



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcement for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced door and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 02BN/01DN/02DN/02DNT/
 02DNU/02MN NARROW LEVER
 TRIM BP-2
 MOUNTING PLATE

HDG. _____ DR. _____

DETEX CORPORATION
 DO NOT SCALE DRAWING
 DATE 7-17-09 TEMPLATE NUMBER T1151