



- NOTES:**
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

<p>RESPONSIBILITY</p> <p>Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.</p>	<p>TEMPLATE</p> <p>WOOD DOOR 08, 09 & 14 EU2W x D / DT / DU / DV WIDE LEVER TRIM - ELECTRIC LOCKING BP-2 MOUNTING PLATE</p>	<p>DETEX®</p> <p>DO NOT SCALE DRAWING</p> <table border="1"> <tr> <td>DATE</td> <td>1-26-16</td> <td>TEMPLATE NUMBER</td> <td>T1199</td> </tr> </table>	DATE	1-26-16	TEMPLATE NUMBER	T1199
DATE	1-26-16	TEMPLATE NUMBER	T1199			