



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
  2. DIMENSIONS SHOWN IN INCHES AND (mm)
  3. USE 98 STRIKE

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**RESPONSIBILITY**

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE  
ALUMINUM DOOR  
1001 & F1001 SERIES  
RIM EXIT DEVICE  
BP-1 or BP-7 MOUNTING PLATE

**DETEX CORPORATION**

DO NOT SCALE DRAWING

DATE 6/21/05

TEMPLATE NUMBER T1105