



NOTES

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
4. FOR MORTISE - SEE T1161

HDG. _____ DR. _____

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 03C/03CV
 WIDE PULLPLATE
 BP-7/BP-13 MOUNTING PLATE

DETEX
 CORPORATION

DO NOT SCALE DRAWING

DATE 06-16-11

TEMPLATE NUMBER T1113