



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

RESPONSIBILITY

Door and Frame Manufacturers are responsible for providing adequate construction or reinforcement for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced door and frames regardless of the type, material or method of construction.

TEMPLATE  
WOOD DOOR  
03 AT, ATN & CHN  
NARROW PULLPLATE  
BP-8 MOUNTING PLATE

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**DETEX**  
CORPORATION

DO NOT SCALE DRAWING

DATE  
6/21/05

TEMPLATE  
NUMBER  
T1117