

of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material, or method of construction.

92 STRIKE (DOUBLE DOOR, SHORT OPEN BACK) FOR MORTISE LOCK

SCALE: NTS TEMPLATE NO: T2004 DATE: 8/29/06