

103106 June 7, 2021

В

Detex Corporation, 302 Detex Drive, New Braunfels, Texas 78130-3045 830-629-2900 / 800-729-3839 / Fax 800-653-3839 / Text photos only: 830-481-6433 / INTERNET: www.detex.com

INSTALLATION INSTRUCTIONS FOR 03WM TRIM

DWG #: 103290

Table of Contents	Page
Device parts breakdown view & part numbers	2
Door Prep - Trim Side, Install Trim, Install Mortise Lock	3
Install Mortise Cylinder, Secure Cylinder	3

TOOLS AND SUPPLIES

Safety Glasses (Always put on safety glasses prior to beginning installation of unit) Pencil Center Punch Hammer Drill Motor Drill Bits & Taps Screw Driver (Phillips Drive) Tape Measure

For WARRANTY information, scan code below or go to www.detex.com/warranty



Owner's Copy



For device installation videos,

scan code below or

go to www.detex.com/videos

103106 Page 1

ITEM	PART NO.	QTY	DESCRIPTION
1	103291-9	1	TRIM PLATE, 03WM, BRUSHED STAINLESS STEEL FINISH (630)
2	102281-X	1	CYLINDER, MORTISE, 5 PIN
3	100752-X	1	CYLINDER COLLAR, TALL
4	100464-9	4	SEX NUT, 1/4-20



