

Detex Corporation, 302 Detex Drive, New Braunfels, Texas 78130-3045 (830)629-2900 / 1-800-729-3839 / Fax (830)620-6711 E-MAIL: detex@detex.com INTERNET: www.detex.com

INSTALLATION INSTRUCTIONS FOR NARROW STILE SVR DOOR KIT - DETEX VALUE SERIES™

## COMBINE WITH PER CHYB. 8.15.22

## **Narrow Stile SVR Door Kit Installation**

**NSK Kit 104750** Slide fillerplate subassembly partially out Using 3/32 hex wrench, loosen 2 set screw (DO NOT REMOVE) Hand tighten set screw after kit is installed 6 Slide fillerplate subassembly back into extrusion. Slide centercase/pushpad subassembly partially out **BSOLETE** Install filler splice from kit Approximately 3" Install extrusion splice from kit & slide centercase/pushpad subassembly back in place 104802 Page 2 OF 2