


## AO19-1 How To Order Single Door Automatic Operator

### HANDING & CONFIGURATION



### ARM OPTIONS

**DEEP** = Required for doors with reveals over 11" (push type only)

**FLAT** = Substitute flat arm (provides 1-3/4" of additional head room at top of door)

### FINISH

**AL** = Clear \*  
**BZ** = Bronze

**AO19-1** x **LH PUSH** x **39.5** x **DEEP** x **Toggle** x **AL**

Sample catalog string

### OPERATOR WIDTH

*For special sizes, contact factory*

**39.5"** = For 36" doors \*

**45.5"** = For 42" doors

**52"** = For 48" doors

### CONTROL SWITCH TYPE

Toggle \*

Keyswitch

**NOTE:** \* = default

