



INSTRUCTIONS FOR ELECTRIFIED MULLION (ADDENDUM FOR 90KRE)

STEP 1: Prep Door Frame




STEP 2: Connect Wires at Top




STEP 3: Prep Mullion (Remove wire harness)

Prep Mullion for Electric Strike or other Electrified Hardware
 (Prep per manufacturer's installation instructions)




STEP 4: Re-Install Wire Harness & Install Electric Strike or other Electrified Hardware (per Mfg's instructions)

RE-INSTALL wire harness in mullion after prepping for strike




STEP 5: Connect Wire Harnesses

WARNING! Ensure POWER IS REMOVED from wires before making connection.



STEP 6: Install Mullion into Top Fitting



For WARRANTY information, scan code or go to www.detex.com/warranty

Owner's Copy

104907

For device installation videos, scan code or go to www.detex.com/videos



Should you have a Question/Problem with your Detex device please call Detex Technical Support from the job site at 1-800-729-3839 and choose option 2 on our menu. Please do not return the product to the distributor.